

THERMAL FLEX

PVC Strip Curtain Mounting Instructions:

1. Using the aluminium channel as a template, make sure channel is level and centred. Opening bar height should allow strips to clear floor 6-10mm mark hole patterns with pencil.
2. Drill holes and mount channel with fasteners provided.
3. Insert one end cap at either end of channel.
4. Insert strips thru un-capped end of channel.
5. After verifying that all strips are evenly placed an overlapping property, insert other cap and trim strips if needed for proper floor height.
6. Optional: Insert self-tapping screws at each end of channel through last strip for added retention.

